



Audion

## Getting Started

Carefully remove your Audion Amplifier from its packaging and store both the box and the foam in a safe place, should, in the unlikely event that you ever need to return your Audion to us for maintenance, upgrading or servicing. The packaging has been specifically designed to protect your amplifier.

Before attempting to connect your Audion please read carefully and understand thoroughly the contents of this manual. Keep this manual near you when installing your Audion so it is handy for reference.

## Please Note.

As with any electrical product extreme caution should be exercised. Do not place your Audion in direct sunlight. There are no user serviceable parts inside. The valves/tubes run **HOT** in normal operation, under no circumstance during operation should they be touched. If it becomes necessary to replace a valve/tube please allow at least 20 minutes from switching off for the unit to cool.

## Valves/Tubes

You will now need to place the valves/tubes into your Audions. The Golden Night Mark 1 and Mark 2 use a CVX120 in the left hand side front and a CVX100 in the right hand side front, and a 300B in the larger rear socket.